


FIG. 1






FIG. 3




FIG. 4A




FIG. 4B




FIG. 4D




FIG. 4E




FIG. 4F




FIG. 4C




FIG. 5




FIG. 6C

FIG. 6C is a screenshot of a portable terminal's address book. The top status bar shows a signal strength indicator, the time 12:34, and a battery level indicator. The screen title is "Address book". Below the title, there is a list of names: "Kyocera, Taro", "Kyocera, Hanako", "Kyocera, Jiro", "Kyocera, Saburo", and "Kyocera, Goro". A cursor is positioned over the first name. At the bottom, there are two buttons: "Back" and "Select".

FIG. 6F

FIG. 6F is a screenshot of a portable terminal's "Compose new mail" screen. The top status bar shows a signal strength indicator, the time 12:34, and a battery level indicator. The screen title is "Compose new mail". Below the title, there are three input fields: "To: Kyocera, Taro", "Title:", and "Message:". At the bottom, there are three buttons: "Send", "Edit", and "Sub. Menu".

FIG. 6B

FIG. 6B is a screenshot of a portable terminal's main menu. The top status bar shows a signal strength indicator, the time 12:34, and a battery level indicator. The screen title is "Main menu". Below the title, there are six options, each with a circular icon: "E mail", "C mail", "EZweb", "Camera", "Address book", and "Confirm Current Position". The "Address book" option is highlighted. At the bottom, there are two buttons: "Back" and "Select".

FIG. 6E

FIG. 6E is a screenshot of a portable terminal's "Compose new mail" screen. The top status bar shows a signal strength indicator, the time 12:34, and a battery level indicator. The screen title is "Compose new mail". Below the title, there are three input fields: "To: Kyocera, Taro", "Title:", and "Message:". At the bottom, there are three buttons: "Send", "Edit", and "Sub. Menu".

FIG. 6A

FIG. 6A is a screenshot of a portable terminal's home screen. The top status bar shows a signal strength indicator, the time 12:34, and a battery level indicator. The screen displays the time "22:34" in large digits and the date "2002/03/28 wed". At the bottom, there are two buttons: "Address book" and "Menu".

FIG. 6D

FIG. 6D is a screenshot of a portable terminal's address book screen showing details for "No. 005". The top status bar shows a signal strength indicator, the time 12:34, and a battery level indicator. The screen title is "Address book". Below the title, there is a list of details: "Kyocera, Taro", "09012345678", "04512345678", "taro@kyocera", "taro@abc", "00 No Group", and "No Position Information". At the bottom, there are two buttons: "Back" and "Open".

FIG. 7




FIG. 8A

12:34

22:34

2002/03/28 wed

Address book Menu

FIG. 8B

12:34

E mail

C mail

EZweb

Camera

Schedule

Confirm Current Position

Back Select

FIG. 8C

12:34

S M T W T F S

2002/07

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24
25	26	27	28	29	30
31					

All Day Conference

Back Select

FIG. 8D

12:34

Schedule

2002/07/17 Wed

All Day Conference

Back Select

FIG. 8E

12:34

Schedule

2002/07/17 Wed

Time: 02/07/17 All Day

Room: Conference Room 1

Location: Company

Content: Prepare Materials

Back Select Open

FIG. 8F

12:34

Edit Schedule

Prepare Materials

Back Confirmation

FIG. 8G

12:34

S M T W T F S

2002/07

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24
25	26	27	28	29	30
31					

Back Select Open

FIG. 8H

12:34

Schedule

2002/07/17 Wed

Time:

Room:

Location:

Content:

Back Select

FIG. 9




FIG. 10A




FIG. 10B




FIG. 10C




FIG. 10D

